

## 99 Ford Ranger EV EPT2 Conversion Wiring Instructions

There are two electrical systems. One 144 volt high current traction circuit and one low voltage control and accessory circuit.

The low voltage circuit is a nominal 12 volt system. It uses a 12 volt accessory battery maintained by a 30 amp Iota DC – DC converter using the 144 volt traction pack as the input source. The 12 volt system (battery and converter) power several components.

We have essential circuits for traction control, essential accessories like vacuum brake system and Power steering system, and optional accessories like Air Conditioner Clutch. Many existing circuits like lighting, radio and blower are unmodified.

The objective is to modify as little as possible and retain and use as much of the existing wiring as possible for new or replacement components. The goal is that all remaining existing functions such as air bags and 4 wheel ABS brakes should continue to function normally. In addition servicing procedures for all remaining existing functions should be unchanged. Wiring diagrams for remaining existing circuits should continue to be useful.

New circuits and modified circuits should be documented with modified diagrams.

- The heavy **Yellow /Light Blue** wire to the starter relay is saved for the new Key Start Function.
- The **Red** wire powering the distributor/ignition module is saved for the Key On function.
- The heavy **Black/Orange (Pink?)** wire from the alternator is saved for the DC – DC converter output.
- The Air Conditioner clutch wires (**Gray/White** and **Black**) are saved for the new A/C clutch circuit.
- The water temperature sender and wire is saved to monitor motor temperature.
- The Inertia Switch **Pink/Black** wire is saved from the fuel tank harness.
- The fuel gauge **Yellow/White** wire and the **Black/Orange** wires are saved from the fuel tank harness for the new traction pack capacity indicator.
- The generator fault light wire **Light Green/Red** is saved from the alternator harness for the new Run Indicator.
- The oil pressure sender wire is saved so that the oil pressure gauge can be used as a vacuum gauge.
- The brake Position Switch **Light Green** wire is tapped for use in the throttle control circuit.

### New Circuits

Key On Interlock  
Run indicator  
Throttle  
Brake Interlock  
Motor Over Temperature Safety Switch  
Power Steering Circuit.

### Modified circuits

Brake Pedal Position Switch  
Vacuum Gauge  
Temperature Gauge  
Fuel Gauge  
Inertia Switch  
A/C Clutch  
DC-DC Converter

## Theory of Operation

### New Circuits

- Key On Interlock

The Key On circuit activates all components and accessories except the throttle circuit.

This circuit is new, but includes a modified Inertia Switch circuit. There are two interlocks which will interrupt the key on circuit, the modified Inertia Switch interlock and the Motor Over Temperature Safety Switch. Both of these switches are normally closed and wired in series. If the motor overheats, the Motor Over Temperature Safety Switch opens and all Key On circuits turn off. The same is true in case of an impact, the Inertia Switch opens and all Key On Circuits turn off.

Key On also activates previously existing functions such as the Computer, speedometer, Air Bags and four wheel ABS.

- Run Indicator

The Run Indicator is described below with other instruments. It is shown in the DC-DC Converter wiring diagram at the lower right. It also appears in the instrument panel diagram at the lower left. This indicator uses the **Light Green/Red** wire from the alternator harness.

- Throttle

The function of the Throttle circuit is to actuate the Main Throttle Contactor and the KSI Relay. This is a complex circuit with several safety features built in. The coils for the Main Throttle Contactor and the KSI Relay are part of the 12 Volt circuit, although the Normally Open Contacts carry 144 volts to the Controller. The KSI Relay is a SPST relay and is so called because it carries 144 volt to the KSI (Key Switch Input) contact on the controller. This turns the controller on.

This circuit starts at the micro switch in the Pot Box. This switch has three contacts, Common (C), Normally Open (NO) and Normally Closed (NC). To simplify otherwise ambiguous terms, NC is referred to here as TD (Throttle Down) and NO is TU (Throttle Up) and Common (C) referred to as (TC).

This switch has two inputs, TU and TC.

#### TU is the initial input.

If throttle is not pressed, TU is the initial input supplied by Key Start leaving the micro switch at TC and headed for the Brake relay, a SPDT, relay, Common. Subsequently TC becomes the input, but we will get to that later.

If the Brake is depressed, the Key Start positive 12 volt signal leaves the Brake Relay at NO (Brake Down). This picks and holds the Interlock Relay, a SPST relay, allowing the Key On signal to enter the Interlock Relay at Common and leave at NO available at the Brake Relay NC (Brake Up).

From this point on the Interlock relay is picked (NO contacts closed) until Key Off or an Inertia Switch interrupt or a Motor Over Temperature Safety Switch Interrupt. While the Brake is not depressed, the Key On signal is not available at TC. As soon as you take your foot off the Brake the Throttle is enabled. From this point on every time you press the Brake the Throttle is disabled.

#### Now TC becomes the input.

When you press the Throttle, the Throttle Micro Switch closes and the Key On 12 volt signal comes from the Brake relay NC (BU) into the Micro Switch TC and out through the TD contact to the KSI relay Coil and the Main Throttle Contactor coil. If you are in any gear other than neutral the car is moving.

Each time the Throttle is pressed the Controller starts and each time the Throttle is released the controller turns off. Regardless of the Throttle position, pressing the Brake will always interrupt the Key On signal to the Micro Switch, and ultimately the KSI and Main Throttle Contactor, and turn off the Controller if it is on.

- Brake Interlock

This circuit has two functions. It provides the path to the Interlock Relay for the Key Start signal, once, at start up. And, it provides the path for the Key On signal to the Throttle Micro Switch. Any time the Brake is pressed, the Brake Relay interrupts the Key On signal to the Throttle Micro Switch.

In addition to the coil suppression diode on all relay, contactor and solenoid coils in this vehicle, the Brake circuit has two additional diodes. Without these diodes the Key Start signal would find its way to the Interlock Relay coil, through either the NO or NC path in the Brake Relay, whether the Brake was pressed or not. At the same time, without these diodes the Key On signal would find its way to the throttle Micro Switch through either the NO or NC path in the Brake Relay.

The diode on the Brake NO (BD) contact allows flow to the Interlock Relay only. The diode on the NC (BU) contact allows flow to the Throttle Micro Switch only.

- Motor Over Temperature Safety Switch

The Netgain Motor has two Black wires at the CE (Commutator End), this is the end oppsite the DE (Drive End). These wires are connected to a normally closed (NC) Over Temperature Switch. If the motor gets too hot the switch opens.

This switch is wire in series with the Key On circuit.

- Power Steering Circuit.

The power steering System has two electrical components, the pump motor and the solenoid control valve. The solenoid control valve is normally open (NO) so that when the pump and the solenoid are without power, steering fluid can flow freely between the steering delivery and return ports. When power is applied to both the pump and the solenoid the solenoid valve closes and free flow is stopped allowing the Power Steering Pump to assist the steering gear. The output of the pump is connected to the steering gear return port and the Steering Gear delivery is connected to the Pump Return.

### **Modified circuits**

- Brake Pedal Position Switch

A positive 12 Volt signal is required to control the Throttle circuit in an emergency. To start the car the Brake pedal must be depressed and any time after that the Throttle should be disengaged when the brake is depressed.

The fuse 13 in the drivers side dash panel fuse panel supplies the Brake Pedal Position Switch. The output of this switch is tapped to power the coil of the new Brake Relay.

- Instruments

- Vacuum Gauge

The Oil Pressure Gauge will be the new Vacuum Gauge. The Oil Pressure Sender really only is an on off switch. The wire from the Oil Pressure Sender will be connected to a vacuum operated relay.

- Temperature Gauge

The Water Temperature Sender with existing wiring will be fastened to the motor to indicate abnormal temperatures at the motor on the existing temperature gauge. It may be necessary to put a resistor in parallel with the sender to get a reading on the existing gauge.

### - Fuel Gauge

The Fuel Gauge wire from the fuel tank harness will be used to connect a new circuit to the existing fuel gauge. A voltage divider will be used to bring the traction pack voltage down from 157 through 144 to drive an opto isolator which will drive a transistor in series with the fuel gauge wire.


This will provide some degree of knowledge about the capacity of the traction pack to an unsophisticated driver.

### Inertia Switch

Both sides of the existing Inertia Switch will be wired in series with the Key On circuit so that the throttle circuit and all other components will disengage in the event of an accident.

### A/C Clutch

The High Pressure Switch and the Low Pressure Switch will be wired in series with a Dash Board SPST Switch to ground,



- **DC – DC Converter**  
The Converter is an AC – DC device. It comes with a three-pin 110V grounded plug on the input. An outlet is provided on the table top for the converter to plug into. The 144V traction battery powers this outlet. The converter can be unplugged from this DC outlet and plugged into any standard 110V AC outlet.

You can see the outlet here on the lower left. The un-switched positive is supplied through an inline fuse from the bottom contact on the Main-Throttle Contactor. This is always hot. The negative side is wired using a black wire directly to the top contact of the Key On-Bypass contactor. This is only hot when Key On. It is important to note that both the positive Main Throttle contactor and negative Key On-Bypass contactor are fed at the bottom

The black wire in the outlet goes to the Chrome screw and the red wire goes to the bronze screw on the outlet.

This image also shows the Run Indicator Relay mounted on top of the Key On-Bypass contactor.



The converter negative output is wired directly to ground. The positive output is wired through an inline fuse to the **Black/Orange**, looks like pin 1 to me, wire from the alternator harness. See diagram.

The Converter, the Vacuum Pump, the Throttle Pot, relays and contactors are mounted on the table top. These low voltage components are connected to off board circuits via two connectors. These are salvaged oxygen sensor connectors, one Green and one purple.



In the lower right corner of this picture, you can see the green and purple connectors. This shows what they look like and where they are located in the finished vehicle.



### IOTA Charge Jack

The wire from dash switch to DC-DC Converter provides the function of the charge jack under switch control. In the left position The converter is putting out 14.2 volts. In the right position it puts out 13.6 volts.  
Black-Green

## Green 4 pin connector

The green 4 pin connector used to connect the ammeter and voltmeter to the table top. the table top side of the green connector for the traction battery gauges in the pod is Wired so that Blue and Green are attached to the battery side of the shunt. Yellow is connected to the contactor side of the shunt and the brown wire is connected to the positive post on the outlet that powers the converter.

On the off table side the green connector is wired as follows. Wire Extension cable is six wire cable, with 12V illumination Red/White, 144V voltmeter Brown/Blue, Ammeter Yellow/Green, +/- pairs. The Red and White wire exit the cable at the fuse panel in the passenger compartment by the drivers door.



Remove Light blue/ Red wire from instrument panel dimmer knob. Use tiny screwdriver to pull wire and contact from plastic plug. Solder short jumper lead to back of contact and reinstall in plug. Put plugs back on head light switch and dimmer knob. Cut shield on cable and pull out Red wire. Put spade type connector on Red wire and short jumper lead from dimmer switch. Connect Red wire to the jumper. The White wire is attached to a convenient ground.




## Purple 4 pin connector

The purple connector carries Key On, Key Start, Brake Down and Run Indicator in the Table Top. Key On and Brake Switch go to the interlock relay panel through the inertia switch and the Motor Temperature safety interlock switch. Key Start goes to the throttle Pot and the Run indicator goes to the Run Indicator Relay mounted on top of the Bypass / Key On contactor.

Key On is taken from the Red distributor ignition wire. Trace this wire back into harness. At its source it splits to power several removed components. Trim this down to one wire.

Key Start is taken from the starter relay wire. This is interlocked with the clutch pedal position switch. Since the clutch has been removed, this interlock needs to be disabled. This was done mechanically by using a bolt to compress the CPPS spring permanently.



A better solution might be to remove the switch and rewire. The clutch cylinder switch, is really three separate single pole single throw switches. When depressed pins 1 to 2 and 5 to 6 are connected. When released pin 3 to 4 is connected.


Or, another choice would be to replace the switch with a relay operated by the new Brake Pedal Position line.

### Connections

KO – Bypass Key On Coil  
 -Interlock common  
 Vacuum Pump  
 KS -Throttle Up  
 TD -Main Throttle Coil  
 -KSI Coil  
 BD - Diode Anode to Interlock Coil  
 BU -Diode Cathode to Interlock Coil  
 BC -TC  
 IO -Interlock Coil  
 -Run Indicator Coil  
 IC -KO  
 KSO -KSI  
 KSC - Main Throttle NO

### Definitions

IO =Interlock On  
 IC = Interlock Common  
 KO = Key On **Green**  
 KS = Key Start  
 TD = Throttle **Down White**  
 TU = Throttle Up  
 BD = Brake Down  
 BU = Brake Up  
 BS = Brake Switch **Red**  
 TC = Throttle Common **Black**  
 BC = Brake Common  
 MTI = Motor Temperature Interlock  
 IS = Inertia Switch Interlock  
 KSI = KSI contact on Controller (Top Post)  
 KSO = KSI Relay NO  
 KSC =KSI Relay Common



The gray brake relay is on the right with the black Interlock relay in the center and the black KSI relay on the left.

The two short White wire bundle and black wires go to the Main Throttle contactor coil. White is positive and black is ground. The short Red wire on the right supplies 144 V to the KSI relay common. It is connected to the top post on the Main Throttle Contactor. The short Red wire on the left goes to the KSI contact on the controller. The two short Green and black wires on the left go to the Key On Bypass contactor coil. Green is positive and black is ground.

The long bundle on the right has the black Throttle Common, the White Throttle Down, the Green Key On and the Red Brake switch. The Red and Green go to an off board purple connector.



### Safety

Not show in the following wiring diagram are the Lock Out - Key Out switches on thee positive and negative terminals of the Traction Battery. Each Terminal has a 500 amp fuse and the a Lock Out switch.



Below you can see the red flag keyed Lock Out Switch. When Key is removed, the positive terminal is open. No connection to the circuit breaker on the table top.


You can also see the green knob, which switches off the accessory battery.



On the right above, you can see the red flag keyed Lock Out Switch. When Key is removed, the negative terminal is open. No connection through the conduit to shunt on the table top. When working on the car, turn the red flag keys and remove them and turn the Green Knob counter Clockwise. At this point it is safe to work on the car. Keep the red flag keys in your pocket, that way nobody can turn the power on while you are working.

Also not included in the wiring diagram are some interlock and the instrumentation circuits.





When the ignition switch is off, everything is off except the voltmeter and ammeter. When the ignition switch is turned on, the Key On - Bypass contactor closes and the DC - DC converter and the Power Steering start operating. At the same time, if the brake is pressed and the throttle is up (not Pressed), while the Key Start Switch is closed, the Interlock relay closes. This allows subsequent normal use of the throttle.

If the brake is not pressed or the throttle is down (Pressed), when the Key Start switch is closed, the Interlock relay stays open and the throttle will not function until it is first released and the brake is pressed. Once the throttle is released and the brake is pressed, while the Key Start Switch is closed, the Interlock relay closes and subsequent normal use of the throttle is allowed.

The diagram shows the throttle in the up position (not Pressed). The interlock relay is closed through the bottom path through the Pot Box micro switch and the brake relay which is shown closed (Brake Down). Once the Interlock relay is closed, it receives power for its coil through its own contacts over the top path. This relay remains closed until the ignition switch is turned off or open.

When the throttle is down (Pressed), the KSI relay and the Main -Throttle contactor close. Power for these coils is drawn through the interlock relay, the brake relay NC contacts and the Pot Box micro switch. The KSI relay turns the controller on which operates the motor under throttle control drawing high current through the Main - Throttle contactor. The controller comes on each time the throttle is pressed and turns off each time it is released. It also turns off when the brake is pressed, even if the throttle is jammed.

### Run Indicator

Use a relay to turn on the charge indicator (an icon of a battery) as a Run Indicator. Use the **Light Green/Red** wire from the alternator harness. . Can't wire it backwards because the Air Bags are on the same fuse. Mount the relay on top of the Bypass/Key On contactor. It gets picked when the interlock relay closes. Tap the NO terminal of the Throttle Interlock relay. The new Run indicator, previously charge indicator, is grounded through the NO contact on the new Run Indicator relay. This indicates that the automobile is on (ready to drive, throttle enabled).



### Vacuum Gauge

The Vacuum pressure switch has three contacts, C, NO, and NC. Use the NC to drive the oil pressure gauge. The oil pressure sensor worked the same way. The needle had only two positions, up (normal) and down (low) pressure. The Gauge will now indicate normal vacuum (up) and loss of vacuum (down).

The switch is adjustable. I found it to be reasonable without any changes.

There is some weight to the idea of having the needle down for normal vacuum and up for loss of vacuum. I like it the other way. The vacuum switch is capable of being wired either way, if desired.

### Temperature Gauge

The sender has two terminals but only one wire on the socket. Find a two wire socket that almost fits on the sender. File off the alignment dog so it fits. Install and solder wires for temperature gauge. Ground the second wire.

### Fuel Gauge




I know how to move the needle but I don't know how to make practical use of it yet. I have a 47 ohm resistor between the Yellow/White wire and the Black/Orange wire in the fuel tank harness. It is indicating one quarter full. Full is 145 ohms and empty is 22 ohms. Without a resistor it indicates way over full.

### Brake Switch

The picture below shows the brake position switch center left and the five wires center right. It looks like a Brown wire on the left and the Light Green with the Red stripe next to it. Next wire moving to the right is a Red wire with a Violet stripe. Next an un-striped Light Green and last Gray wire.

Research on the Auto Zone web site shows a simplified wiring diagram indicates the brake switch supplied by a Light Green wire with a Red stripe and an un-striped Light Green wire coming out of it.





Further evidence is the fact that the two Light Green wires are of a heavier gauge than the others. Tap the un-striped Light Green wire. Pull the wire bundle open and separate it from the switch to get access to the wire for the tap.

Use a diode to make sure no 12V signals from the table Top find their way into the brake control system. Run the new brake wire out the door and do a few tests show that the wire was providing 12 Volts to the coil of the brake relay on the Table Top.

The diode should be connected so that the band (the Cathode) points to the brake Relay. This allows flow from the brake pedal position switch to the brake relay coil and then to ground. Reverse flow is prevented.

After testing, the wire is routed through the firewall with the wires from the instrument pod through the hole previously used by the Clutch Push Rod. A harness can then be wrapped with these wires and the Key On and Key Start wires. The third wire is now added to the Purple connector to the table top, giving us Key On, Key Start and Brake Down in the connector.


## Remaining Interlocks

Wire the Over Temperature safety interlock switch in motor. These two wires are wired in series with the Key On wire before it goes to the Table Top. The Inertia Switch is part of this series sequence. A severe impact or motor over heating will interrupt Key On. In This case the car can not be restarted until the condition is cleared, the brake depressed while the key turned to the key start position.

A bundle was created including the Motor Over Temperature Safety Switch and the motor temperature sensor. These wires were included in a harness that terminates near the fuse box. The wires for the A/C sensor in the high pressure line were included in a separate harness.



## Inertia Switch



The factory Inertia Switch is located on the firewall under the glove box. The wires are integrated in the fuel tank harness.

Research on the Gas gauge, leads to the fact that the inertia switch **Pink/Black** wire is in the Fuel Tank harness. Further research shows that the **Green/Yellow** input to the inertia switch is from the fuel pump relay, which is located in the fuse box under the hood. Relay number 5 (between 4 and 7 Shown removed) on the far right is the one. Remove and discard the relay. The NO contact (pin 5) is the lower, or large center slot, of the two horizontal contacts just above the row of three smaller vertical contacts. A wire with a spade connector is inserted here. The **Pink/Black** wire in the Fuel Tank harness is the other.

The Fuel Tank harness is separated from the harness running along the frame to the rear bumper up to a point under the cab. From there it is folded forward and routed to the engine compartment. The inertia Switch is then wired in series with the motor over temperature switch in the Key On wire. The gas

gauge wire harness is conveniently located for future enhancements.


Put a spade connector on the Key On wire and plug it into Pin 5 of the Fuel Pump Relay socket (Relay #5).



This sends the Key On signal over the **Green/Yellow** wire to the Inertia Switch. It goes through the Inertia Switch to the **Pink/Black** wire. Put a plug on the Motor Over Temperature wires. Connect the **Pink/Black** wire to one of the wires from the Motor Over Temperature Plug. This forwards Key On through the Over Temperature Switch and Plug to the other wire. Connect this to the Purple Connector going to the table top.


Here you can see the routing of the Key On wire to Pin 5 of the fuel Pump Relay Which goes to the Inertia Switch wire between relays 4 and 7. You can also see the modification to relay #2 described below.





The inertia Switch wire is **Pink/Black**. A gentle tap, with a small hammer, on the inertia switch shows that the power to the table top is lost when the inertia switch trips. Pressing the reset button on top of the switch allows the ignition switch to be used to restart.

### Air Conditioner Control



Test the A/C with a jumper wire on pins 3 and 5 in the fuse box where the A/C relay #2 is. It should cool even at the low RM provided by the motor at 12 Volts, with the compressor load on it. Rewire the compressor.

- 1- Coil
- 2- Coil
- 3- C (Common)
- 4- NC (Normally Closed)
- 5- NO (Normally Open)



The computer will not provide ground to the coil on the compressor relay due to the fact that the ICE is not running (I wonder why). Take the cover off the relay and add a ground wire to pin 1 on the coil, which runs out of the Fuse box to ground. The problem with just this modification is that the compressor clutch comes on with Key On and stays on until Key Off.

There are two sensors monitoring pressure, one on the high side and one on the low. The computer uses these inputs to turn the compressor off when appropriate. The sensors are normally closed switches. They have to be taken away from the computer. The black/Yellow wire goes from the computer to the low side and the Red/Yellow goes from the low side to the high side. The black/White wire goes from the high side to ground.

The strategy is to take the black/Yellow and the black/White and make a ground line for the compressor coil. Trace the black/Yellow wire from the Accumulator to the drivers side of the condenser right next to the High side sensor. Join the black/White wire to the ground wire added to Compressor relay coil.

Take the black/Yellow wire and solder a long White wire to it and rout it into the passenger compartment through the fire wall. You can leave a long loop under the hood near the fuse box. The plan is to put a switch on the dash to provide the final ground for the compressor relay coil. The loop under the hood can be cut to insert a ground interrupt when the throttle is up and the motor is not turning (optional).

Remove the escutcheon around the radio and cut a rectangular hole for a rocker switch. The switch is a SPST. We still have to wire it and put everything back together. Although it isn't finished yet, test the Compressor Clutch wiring by touching the White ground wire to the chassis. Also disconnected the low side and high side sensors one at a time to be sure the clutch will stays off. The final setup should provide normal A/C operation with two exceptions. First, you will have to turn on the compressor rocker switch on in addition to the normal A/C controls. Second, the A/C will not operate when the car is stopped.


Reinstall radio escutcheon with new Compressor Clutch Switch.





The rocker switch is next to the radio on the left.

## General Information

This drawing shows how to use a 100 volt 3 amp suppression diode on a relay coil.



This diagram shows proper orientation of diode with schematic.



This is a picture of a single pole double throw relay pin-outs. The center pin 87a is normally closed. The top pin, 87, is normally open. It closes (is picked) when the coil is actuated. The bottom pin, 30 is common. Any signal applied here is routed to 87a normally and 87 when the relay is picked. The remaining two pins on each side, 85 and 86, are the coil connections. This is where the suppression diode is connected. It must be connected so that the band at the cathode is on the plus 12 volt side of the coil.

Sockets are available for these relays. They can be wired with spade connectors, but a socket is easier if replacement becomes necessary

The term Multi Function Switch used in wiring diagrams refers to the switch in the directional signal arm used for wipers, lights and such.





[illegible]

With voltage applied, regulator is activated, allowing current to flow from sense A circuit to generator field coil. Generates an AC output which is converted to a DC output by a rectifier assembly internal to generator, and is supplied to vehicle through the B+ terminal. S (stator) circuit is used to feed back a voltage signal from generator to regulator. This voltage (typically half battery voltage), is used by regulator to turn off indicator.



Illustration 4: Inertia Switch Wiring Diagram.



P.O. BOX 11846 TUCSON, AZ 85734  
 (520) 294-3292 • FAX (520) 741-2837  
[www.iotaengineering.com](http://www.iotaengineering.com)

The IOTA Power Converter/Battery Charger converts 120 volts nominal A.C. to 13.6 volts D.C. As a power supply, its tightly controlled regulation allows the user to operate any 12 volt nominal D.C. load up to the converter's rated output current. As a battery charger, the converter will maintain the battery, delivering its full-rated current when the battery capacity falls sufficiently low. The voltage is set to deliver its maximum current for the necessary period of time that minimizes undue stress to the battery caused by heating of its cells. This helps to ensure the longest possible life of the battery. Over time, as the battery nears its full capacity, the converter will float-charge the battery to prevent self-discharge of its cells.

### PROTECTION FEATURES


The IOTA Power Converters/Battery Chargers are designed with high quality components to help ensure years of continuous use. The unit is protected by multiple protection features for a long, trouble-free life.

1) *Reverse Battery Polarity Protection.* 2) *Brown-Out Input Protection.* 3) *Over-Current Protection* - cycle by cycle peak limiting as well as rated current limiting to maximize the life of the converter. 4) *Over-Temperature Protection.* In addition, it is designed with a unique "proportional" fan control circuit. Fan speed is directly proportional to the converter's internal ambient temperature. This enables the fan to turn on and off very slowly, minimizing unwanted fan-starting noise.

### WARRANTY

The IOTA Power Converters/Battery Chargers are warranted from defects in materials or workmanship for two years from date of retail purchase, and limits the remedies to repair or replacement. This warranty is valid only in the continental United States and Canada. For complete warranty details, contact Customer Service or visit [www.iotaengineering.com](http://www.iotaengineering.com).

## ***IOTA POWER CONVERTER/CHARGER*** **OWNER'S MANUAL**



MODEL	DLS 15 SERIES M	DLS 30 SERIES M	DLS 45 SERIES M	DLS 55 SERIES M	DLS 75	DLS 90
INPUT VOLTS (Vac)	108-132	108-132	108-132	108-132	108-132	108-132
FREQUENCY (Hz)	47-63	47-63	47-63	47-63	47-63	47-63
MAX AMP DRAW (AC)	3.5	7	11	13	17	21
MAX WATT DRAW (VA)	250 (390)	500 (770)	750 (1160)	950 (1460)	1300 (2000)	1500 (2300)
OUTPUT AMPS (DC)	15	30	45	55	75	90
OUTPUT VOLTS (DC)	13.6 NOMINAL 13.4 @ FULL LOAD					
DIMENSIONS*						
WIDTH	9.7"	9.7"	9.7"	9.7"	6.5"	6.5"
LENGTH	6.7"	6.7"	6.7"	6.7"	10"	10"
HEIGHT	3.4"	3.4"	3.4"	3.4"	3.5"	3.5"

\*DETAILED MOUNTING SPECIFICATIONS ARE AVAILABLE  
 ONLINE AT [WWW.IOTAENGINEERING.COM](http://WWW.IOTAENGINEERING.COM)

Distributed By:

## INSTALLATION GUIDELINES

There are no components within the IOTA Power Converters/Battery Chargers that, in their normal operation, produce arcs or sparks. However, all electronic devices have some potential for generating sparks in the event of failure. Therefore, never install this device in the same compartment with flammable items such as gasoline or batteries.


### MOUNTING LOCATION

The IOTA Power Converter/Battery Charger can be mounted in any position within an enclosed or interior compartment. Provide sufficient air space to allow unrestricted airflow in and around the unit.

### INSTALLATION

Disconnect the positive side of the battery before installation. Connect the positive (red) and negative (black) terminal lugs to battery or load. Always use the proper size wire based on the amperage of the converter and the battery. When connecting to a battery, a breaker should be installed within 18" of the battery, connecting the battery positive to the line side of the breaker, and the IOTA unit to the load side. Connect "Chassis Bonding Lug" on the IOTA unit to vehicle chassis or other grounding source.

#### DLS MODEL\*




### 120 VOLT A.C. INPUT

Plug the unit A.C. input cord into a 120 volt 3 wire grounded source. See chart for maximum current draw and required input voltages.

### REVERSE POLARITY FUSES

The IOTA Battery Charger/Power Supply is protected against reverse polarity on the DC output. If a battery or the unit is hooked up incorrectly, the fuses will blow and can be easily replaced. Always use the same size and style fuse that came with the converter. To change the fuses, use a screwdriver to loosen the screws and remove the fuses. Always replace the fuses with the same type and rating. After inserting the new fuses, tighten the screws firmly. Apply 5 inch-pound maximum torque. DO NOT OVERTIGHTEN.

#### DLS SERIES M MODEL\*



\*Actual component locations may vary depending on model.


## CHARGE CONTROL

### TWO-STEP VOLTAGE JACK

The two-step voltage jack allows switching from a long-term float voltage of 13.6vdc up to 14.2vdc. When the included dual voltage plug is inserted in the jack\*, the voltage rises to 14.2vdc for occasional fast charging. When the plug is removed, the voltage drops to 13.6vdc to reduce battery water loss. **WARNING: To avoid battery damage, remove the Dual Voltage Plug when quick-charging is complete.** NOTE: If the unit is equipped with an internal IQ4 smart charger, two-step charging is not needed and the Dual Voltage Jack is disabled.

\*Location of the Dual Voltage Jack may vary depending on model.

#### DUAL VOLTAGE PLUG



### THE IQ4 LED INDICATOR

(ONLY ON IOTA MODELS WITH INTERNAL IQ4)

IOTA Models with an internal IQ4 smart-charger give the user the benefit of automatic Bulk, Absorption, and Float stage charging. This increases the charging capacity of the IOTA charger, decreases charge times and insures proper and safe battery charging without over-charging. The green LED on the fan end of the unit will indicate which charging phase the IOTA unit is currently in. When the unit is first activated, the LED will flash as it reads the number of cells in the battery. The unit will then proceed directly to the Bulk charging or Float charging phase depending on the charge status of the battery. Use the LED CODE TABLE for reference when checking the LED. Units that do not have an internal IQ4 smart-charger can easily install an external IQ4 that plugs into the available Dual Voltage Jack. Contact Customer Service for more information.

#### LED CODE TABLE

CELL INDICATION		
6 FLASHES	12V Battery (6 cells)	
12 FLASHES	24V Battery (12 cells)	
18 FLASHES	36V Battery (18 cells)	
24 FLASHES	48V Battery (24 cells)	
CHARGE PHASE	LED STATUS	VOLTAGE RATE
FLOAT	ON	2.26 PER CELL
ABSORPTION	SLOW FLASHING	2.36 PER CELL
BULK	RAPID FLASHING	2.46 PER CELL

## Table of Contents

Wiring Instructions.....	1
New Circuits.....	1
Modified circuits.....	1
Theory of Operation.....	2
New Circuits.....	2
Modified circuits.....	3
IOTA Charge Jack.....	5
Green 4 pin connector.....	6
Purple 4 pin connector.....	7
Connections.....	7
Definitions.....	7
Safety.....	8
Vacuum Gauge.....	11
Temperature Gauge.....	11
Fuel Gauge.....	11
Brake Switch.....	11
Remaining Interlocks.....	12
Inertia Switch.....	13
Air Conditioner Control.....	14
General Information.....	16